



Product Safety Recall



Ryobi and Homelite Petrol Line Trimmer/Brushcutters and brushcutter blades.

Ryobi Models: RBC254FSDSN RBC254FSBSN, ABCLT04G

Homelite Models: HBC25SJSN, HBC30SBSN

Blade Attachments Models: RAC1101 or LTA024

Sold at Bunnings stores nationwide from
October 2013 to April 2016



What is the Problem? If the nut securing the blade is not properly tightened before use, in accordance with the instructions, the blade may detach.

What is the Risk? If the blade detaches during use, it could hit and cut you or bystanders.

What to do: Immediately stop using the blade attachment and to contact Techtronic Industries N.Z. Limited to either:

1. return the Product (as a whole) for a refund of the full purchase price of the Product; or
2. return the Blade (only) for a refund of the full retail price of the Blade.

Contact Details: For more information:

Free Call: 0800 028 491

Mail: PO Box 12-806, Penrose, Auckland 1642

Email: info@ryobi.co.nz

Website: www.ryobi.co.nz

See www.recalls.govt.nz for New Zealand
Product Recall Information